

Portable Antenna Controller (PAC-I™) User's Guide



Document: KC-50-0001-03

10/17/2005



2004 KMW Communications, Inc. All rights reserved

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose without the express written permission of KMW. KMW hereby authorizes its customers to make copies of this documentation in CD-ROM form to customer's own computers for use in conjunction with the products described herein.

Information in this document is subject to change without notice. KMW assumes no liability for omissions or inaccuracies in this document, or from the furnishing or use of the information herein. KMW reserves the right to make changes to any products described herein and does not assume any liability arising out of the applications or use of any product described herein.

This document and the information in it is the proprietary and confidential information of KMW that is provided by KMW to its customers pursuant to a contract for the purchase of the products described herein. If the possessor of this document is an entity or individual not party to a sales contract with KMW, or is not otherwise intended by KMW to receive this document and the information in it, you are hereby notified that such possession is unauthorized and is in derogation of KMW's proprietary interests. If you are in unauthorized possession of this document, please return it immediately to KMW at the address contained herein at KMW's cost.

Date	Version	Description
06/06/2004	KC-50-0001-Draft Version	Initial production release of the portable
		antenna controller (PAC-I) for KMW remote
		controlled antenna products.
07/20/2004	KC-50-0001-01	Production release
10/22/2004	KC-50-0001-02	Revision update
04/13/2007	KC-50-0001-03	Company information change

Revision History

If you have questions or comments about the content of this document, please contact:

KMW Communications

1521 East Orangethorpe Ave. Suite A. Fullerton, CA 92831 714-895-3659 http://www.kmwcomm.com support@kmwcomm.com



9. Troubleshooting Guide

Item	Code (Hex)	Description	
Same Code Over Count	0x01	Current position was detected after a fixed number of	
		trials. Check torque or control voltage.	
Open Code Over Count	0x02	Open value was detected after a fixed number of trials.	
		Check connections between Bias-T, cable, and antenna.	
Unknown Code Detection	0x04	Unknown position value was detected. Failure due to	
		motor box encoder inside antenna, Bias PCB, Bias-T, AD	
		converter of the controller, etc.	
Maximum Limit Detection	0x08	Out of control range. Failure due to motor malfunction	
		or incorrect actuating voltage.	
Minimum Limit Detection	0x10	Out of control range. Failure due to motor malfunction	
		or incorrect actuating voltage.	
Next Code Not Detection	0x20	Control position failure. Failure due to insufficient	
		torque, motor encoder, etc.	
Miss Path Detection	0x40	Failure in control path relay, controller, incorrect position	
		of motor during antenna assembly, etc.	

9.4. Description of Alarm Codes

Note: The above alarms include failures that may not be repaired by end-users. Contact KMW Technical Support for further assistance.

9.5. General Information

- PAC reset while operating: This may be caused by insufficient amount of remaining battery power. Check the battery level and recharge if necessary.
- Recovering from Alarm:

For any alarms listed above (Table 6-1), the PAC automatically recovers from the alarm. If an alarm continues to appear, user may try to recover from the alarm by pressing 'ENT' key after alarm appeared. If the alarm continues after the manual recovery process, contact KMW Technical Support for further assistance.





Table of Contents

1.	Preface	5
1.1	Purpose	5
1.2	General Information	5
1.3	Related Documents	5
2.	Overview of Portable Antenna Controller Kit	6
2.1	Controller Kit Packing List	6
2.2	Controller Functions	7
2.3	PAC-I Operating Requirements	7
3.	Overview of PAC-I	8
3.1	External View	8
3.2	Part Description	9
4.	Preparation	10
4.1	PAC-I Packing List	10
4.2	Power Supply/Battery	10
4.3	Connecting PAC using Control Cable	11
4.4	Connecting Optional PAC Communication Cables	11
4.5	Connecting Optional PAC Communication Cables	12
5.	Operating PAC-I	14
5.1	Key Functions	14
5.2	Verifying User ID and password	15
5.6.	Antenna Beam Direction Control	19
<i>6</i> .	PAC Menu Structure	22
6.4.	Menu Diagram	22
7.	PAC PC Application User's Guide	23
7.4.	Operating Environment	23
7.5.	Program Installation and Execution	23
7.6.	Start-up Window	23
1.1.	Getting Started	25
8.	Cautions	31
9.	Troubleshooting Guide	32
9.4.	Description of Alarm Codes	32
9.5.	General Information	32
10.	Portable Antenna Controller Specifications	33



11.	Technical Support	33
Read	er Survey Form	34



1. Preface

1.1 Purpose

- 1.1.1 The purpose of this document is to explain how to operate PAC-I (Portable Antenna Controller – First Edition of Controller Series: herein "PAC-I") for antenna beam control of KMW's adjustable antennas (1-Way EDTA, Hybrid 2-Way Antenna).
- 1.1.2 The main use of this portable, easy-to-carry controller is to control vertical and horizontal beam width of KMW's adjustable antennas.
- 1.1.3 The purpose of PAC-I is to increase the effectiveness of base station operations by offering easier and cost-effective network optimization through remote control capability of antenna beam direction control.

1.2 General Information

- 1.2.1 By incorporating RS-485/422 communications interface, PAC-I is designed to be interoperable with the base station systems.
- 1.2.2 By incorporating RS-232 communications interface, PAC-I supports the value-added features such as user registration, antenna beam control data log management, firmware download, etc.
- 1.2.3 PAC-I is designed to be portable and user-friendly and features Graphic LCD Screen and 4×4 key function.

1.3 Related Documents

- 1.3.1 PAC-I Specifications
- 1.3.2 Communications protocol between PAC and PAC PC Application software (KMW proprietary protocol)



2. Overview of Portable Antenna Controller Kit

Items Qty. Size		Part Number	
PAC-I KIT	1 -		KMDAN0104000
PAC-I	1	Refer to product specification in Section 10	KMDAN0103000
Rechargeable Battery (included in PAC-I)	1	3.7V, 3CELL(11.1V, 1.5A) LI-POLYMER	PXZZMD0280A
AC/DC SMPS Adaptor	1	Input: 100~240V, 50/60Hz 1.5A Output: 19VDC, 3.68A 70W	XW01MD028ZA
AC Power Cable	1	250V, 2M	XMJ0MD028ZA
AC Power Plug	1	220V to 110V	PXZZMD0281A
Control Cable	1	SMA(M)-to-SMA(M), RG316Type, 2 meter	KCA051011056
RS-232 Cable	1	DSUB(M) to DSUB(F), 2 meter	WA01MD0519A
Bias-Injector with DIN-Barrel Adaptor	1	-	KASCTR182019
Shoulder Strap	1	2 meter	PXZZMD0282A
Carrying Case 1		410×310×125 mm	GC91MD0519A
User guide 1		-	KC-50-0001-02
Program CD 1 PAC PC Application		PAC PC Application	-
Adaptor 1 DIN(M) – DIN(M)		DIN(M) – DIN(M)	KAD828211000

2.1 Controller Kit Packing List

Figure 2-1. Inside View of PAC Kit





2.2 Controller Functions

- Vertical (electrical) and/or horizontal (mechanical) antenna beam control
- Antenna model (EDTA 1-way, Hybrid 2-way) and sector selection
- User ID and password input for security protection
- Base station ID input for history log
- Data interoperability between PAC and PAC PC Application
 - Registration of user ID and password
 - o Registration of base station ID
 - Antenna control data upload and management
 - Firmware (F/W) download
- Power detector and indicator
 - AC/DC Adaptor connection detector
 - o Battery level indicator
- Time and date display
- Automatic speed control of antenna beam controlling motor
- Automatic recovery of antenna control alarm
- Various communications protocol support
 - RS-232: PAC-I \leftrightarrow PAC PC Application
 - o RS-485/422: PAC-I \leftrightarrow Base station systems

2.3 PAC-I Operating Requirements

- PAC-I allows antenna control of KMW's remotely adjustable antennas only.
- User has the basic operations knowledge of the KMW current antenna products. For new antenna models KMW develops in the future, user may need to update the software.
- PAC-I uses rechargeable battery as its main source of power, and user should frequently check and charge the battery to maintain its optimal power level.
- Although PAC-I has Super User ID and BTS ID already stored in it, it is advised that the user registers its own user ID and BTS ID using PAC PC Application software in order to secure and manage the data effectively.



3. Overview of PAC-I

3.1 External View

Figure 3-1. External View of PAC-I





3.2 Part Description

- RS-232 Port: This is for communication between PAC-I and PAC PC Application software (RS-232 communications standard) installed on a PC.
- ANT Port:

This is for antenna beam control. Connect DC input port of Bias-T and ANT Port with Control Cable.

- RS-485/422 Port: This is for communication between PAC-I and base station systems. For its use, protocol should be discussed with the customer.
- Shoulder Strap Holder: Used to hold shoulder strap.
- Display Window: Displays the date, time, battery level, and antenna control information and status.
- Membrane S/W:

This is the keypad to input antenna control information. 4×4 Matrix Key Function is used to enhance easy operation and support multiple functionalities PAC-I offers.

- Power Switch: Switch for power supply.
- AC/DC Adaptor Input Port: This is the input port for outside power supply. It connects PAC-I to outside power supply in case the built-in battery dies or does not have enough power charged to operate PAC-I.



4. Preparation

4.1 PAC-I Packing List

User should make sure that there is no missing part from PAC-I Kit to prevent any control failure or error during operation. (Refer to Section 2.1)

4.2 Power Supply/Battery

After turning on the power switch of PAC-I, user should check the battery indicator located on the top right corner of LCD screen to verify if the battery is charged sufficiently to operate PAC-I. If this indicator blinks every second, user needs to recharge the battery.



Figure 4-1. View of LCD Screen

Battery Indicator	Power Level	
	75% to 100% full	
	50% to 75% full	
	25% to 50% full	
<u>۲</u>	Below 25% full	
<u>۲</u>	If power level is below 20%, the indicator blinks every second to warn the user to recharge.	



4.3 Connecting PAC using Control Cable

As shown in Figure 4-3, connect DC input port of the Bias-T to the ANT port of the PAC using the SMA(M)-to-SMA(M) RG316 type control cable.





Important: There should be direct DC path from the PAC through Bias-T to the antenna in order for the remote control signal to flow up to the antenna. If additional lightning protection is required, use a lighting arrestor with DC bypass feature.

4.4 Connecting Optional PAC Communication Cables

When configuring PAC using the PAC PC Application software or connecting PAC to the base station, use RS-232 cable (included in the PAC Kit) and/or RS-485/422 cable (not included in the PAC Kit) to connect the PAC to a PC or to a base station system as shown in Figure 4-4.





Figure 4-4. Interface between the PAC-I and Personal Computer/Base Station System

Note: RS-485/422 cable is not included in the PAC Kit.

4.5 Connecting Optional PAC Communication Cables

KMW's remotely adjustable antenna products follow the following direction conventions. When using the Portable Antenna Controller, please refer to the following conventions for the changes in the peak gain direction.

The positive horizontal beam steering angles mean clockwise rotation from the boresight of the antenna (i.e., the perpendicular direction of the mounting surface) and the negative horizontal beam steering angles mean counterclockwise rotation from the boresight of the antenna.

As for the vertical downtilt, the positive angles mean the electrical downtilt angles, and no electrical uptilt is currently available.





Figure 4-5. Antenna Configuration Direction Convention



5. Operating PAC-I

5.1 Key Functions

1	2	3	SEL
.QZ	ABC	DEF	MENU
4	5	6	FWD
GHI	JKL	MNO	
7	8	9	REV
PRS	TUV	WXY	
•	0	►	ENT

Figure 5-1. Key Pad Layout

5.1.1 Numeric (Character) Key Used when inputting password, time, date and etc.

5.1.2 Function Key

- 'SEL/MENU' Key Used to change antenna configuration (vertical, horizontal). To select the MENU option, press SEL/MENU key for more than a second.
- 'FWD' Key Used to increase (targeted) antenna steering angle. Also used when selecting MENU (UP Key).
- 'REV' Key Used to decrease (targeted) antenna steering angle. Also used when selecting MENU (DOWN Key)
- 'ENT' key Used to select menu and activate antenna control.
- 5.1.3 Shift Key
 - Left Shift Key (◀) Used to move cursor to the left.
 - Right Shift Key (▶)
 Used to move cursor to the right.



5.2 Verifying User ID and password

In order to prevent unauthorized use of PAC and to track/manage user data, all users must go through the user verification process.

1.	Check to make sure that ANT Port(F) on PAC is connected to DC Input Port(F) on Bias-T with SMA(M)-to-SMA(M) Control Cable.	
2.	Turn on the power switch at the bottom of PAC-I.	PAC-I TM VER:1.1.2.01
3.	Select USER ID by using left (◀) or right (►) 'Shift' key, then pressing 'ENT'. User can register up to 10 USER ID's using both PAC-I and PAC PC Application.	01/01 00:00
4.	Type in four-digit password. Note: If the inputted password is correct, the next screen will appear automatically. If the password is incorrect, it will flash "Retry!" then ask for the password again.	01/01 00:00 C
5.	If the correct password is entered and the user is verified, the MENU screen will appear.	01/01 00:00



5.3. Menu

MENU brought up during antenna beam control has the same menu items and uses as the MENU appeared in the beginning. To bring up MENU while controlling antenna, press 'SEL' for more than a second. Re-press 'SEL' to go back to the previous screen.



[1] Setup : Selecting different options for antenna beam control and data management.

- [2] Antenna Control : Vertical, Horizontal, Beam Width control
- [3] Measurement VSWR : Measuring VSWR. It is not used currently.
- [4] Memory Clear : Deleting antenna beam control data stored in memory.

5.4. Setup

While on the above MENU screen, press '1' on the keypad to bring up 'Setup' menu. To go

01/01	00:00	
	SET L	JP
[1] Us	ser Chang	le
[2] BT	S Num. C	Change
[3] Da	ate Set	
[4] Tir	me Set	

back to the previous menu, press 'SEL.'

5.4.1. [1] User Change

Used to change the current user. From SET UP menu screen, press '1' on the keypad to select 'User Change.' In order to cancel the selection, press 'SEL' and go back to the previous menu.

1.	Using Left(\blacktriangleleft) or Right(\triangleright) 'Shift' Key,	01/0	1 00:00	
	press 'ENT.' User can register up to 10		USER	
	USER I/Ds using both PAC-1 and PAC			
	PC Application.		Super ID	





2. Type in four-digit password. Note: If the inputted password is correct, the next screen will appear automatically. If the password is incorrect, it will flash "Retry..!" then ask for the password again.



5.4.2. [2] BTS Num. Change

Used to change the BTS Number. From SET UP menu screen, press '2' to select 'BTS Num. Change.' In order to cancel the selection, press 'SEL' and go back to the previous menu.

Using left(◀) or right(►) 'Shift' Key, select the registered BTS Number and press 'ENT ' Up to 10 BTS Numbers can	01/01 00:00
be registered using PAC PC Application.	KMW BTS

5.4.3. [3] Date Set

Used to set the date. From SET UP menu screen, press '3' to select 'Date Set.' In order to cancel the selection, press 'SEL' key and go back to the previous menu.

1.	Using the keypad, input the DATE. The	01/01
	cursor automatically shifts to the right	
	when numbers are entered, however, it	
	can also be moved by pressing left(\blacktriangleleft) or	
	right(\blacktriangleright) 'Shift' key. Press 'ENT' to	Г
	complete the date set up.	
	1 1	

01/01 00:00 C

5.4.4. [4] Time Set

Used to set the time. From SET UP menu screen, press '4' to select 'Time Set.' In order to cancel the selection, press 'SEL' key and go back to the previous menu.

		 F
2.	Using the keypad, input the TIME (00:00	01/01 00:00
	~ 23:59). The cursor automatically shifts to the right when numbers are entered.	TIME SET
	however, it can also be moved by	
	pressing left(\blacktriangleleft) or right(\blacktriangleright) 'Shift' key.	00:00
	Tress ENT to complete the date set up.	



5.5. Antenna Control(Finding current antenna beam configuration)

This menu is for antenna beam controls. User must go through the below steps to control antenna beams. From the main MENU screen, press '2' to select 'Antenna Control.' In order to cancel the selection, press 'SEL' key and go back to the previous screen.

- 5.5.1. Antenna Type Selection
 - 1. Using left(◀) or right(►) 'Shift' Key to select the ANTENNA TYPE to be controlled and press 'ENT.'
 01/01 00:00

 ▲ HBRD 2-Way
 ▲

* Antenna Type List

/1	
Antenna Type	Description
EDTA 1-Way	Vertical beam tilt capability
HBRD 2-Way	Vertical beam tilt and horizontal steering capability
<3> Sector	3 Sector Antenna control
Dual Band	Vertical beam tilt and horizontal steering capability for 2 different
	frequency band
Qaud Band	Vertical beam tilt and horizontal steering capability for 2 same
	frequency band
<3> Column	Beam width control and horizontal steering capability

5.5.2. Antenna Model Selection

Select Antenna Model for the Antenna Type selected in the above menu.

 Using left(◀) or right(►) 'Shift' Key to select the ANTENNA MODEL, and press 'ENT.' 	01/01 00:00
	 <imt2000> HB−X</imt2000> −IB−17−65−00T



Antenna Moder by Antenna Type			ype		
Antenna	Antenna Model	Ver No.1	Ver No.2	Horizontal	Remark
Туре		Range	Range	Range	
	AM-X-CB-15-65-00T	0°~14°	-	-	Cellular 800
	AM-X-CB-15-65-06T	6°~20°	-		Cellular 800
	AM-X-CB-17-65-00T	0°~14°	-	-	Cellular 800
EDIA 1 Way	AM-X-GB-15-65-00T	0°~14°	-		GSM 900
1-way	AM-X-DB-17-65-00T	0°~16°	-	-	DCS 1800
	AM-X-PA-17-65-00T	0°~16°	-	-	US PCS
	AM-X-IB-17-65-00T	0°~16°	-	-	IMT 2000
	HB-X-CB-15-65-00T	0°~14°	-	-30°~ +30°	Cellular 800
	HB-X-GB-15-65-00T	0°~14°	-	-30°~ +30°	GSM 900
2 Way	HB-X-CB-15-65-06T	6°~20°	-	-30°~ +30°	Cellular 800
2- vv ay	HB-X-PA-17-65-00T	0°~16°	-	-30°~ +30°	US PCS
	HB-X-IB-17-65-00T	0°~16°	-	-30°~ +30°	IMT 2000
<3>Sector	E3-X-CB-15-65-00T	0°~14°	-	-	Cellular 800
<3>5ector	H3-X-PA-17-65-00T	0°~16°	-	-15°~ +15°	US PCS
Dual Band	HD-X-CA-FH-65-00T	0°~16°	0°~14°	-30°~ +30°	US PCS /
					Cellular 800
Quad Band	HQ-X-PA-17-65-00T	0°~16°	0°~16°	-30°~ +30°	US PCS*2
<3>Column	НН-X-PA-18-VA-02T	35°,65°,	-	-30°~ +30°	Beam
		90°,120°			Width

* Antenna Model by Antenna Type

5.5.3. Antenna Sector Selction

Select Antenna Sector for the Antenna Model selected in the above menu.

1.	Using left(◀) or right(►) 'Shift' Key to select the ANTENNA SECTOR to be controlled and press 'ENT.'	01/01 00:00
2.	When all the above set up process is completed, PAC will automatically start finding the current antenna configuration, and when it's found, PAC allows user to control/change antenna beam configuration.	01/01 00:00 HB-X-IB-17-65-00T[a] ► VB1: 0.0° [OK] HB1: 0.0° [OK] VB2:° []

5.6. Antenna Beam Direction Control

5.6.1. LCD Screen





- Date & Time: Current date and time
- Battery Info.: Indicate battery power level
- Antenna Model: Controlling antenna model
- Antenna Sector: Controlling antenna beam sector
- Current Beam Degree: Steering antenna beam angle (vertical, horizontal)
- Beam Status: Antenna beam status

5.6.2. Changing Control Path (Vertical, Horizontal, Beam Width) Change control path using 'SEL/MENU' key. Each time 'SEL/MENU' key is pressed, different control path (vertical or horizontal) is selected; this does not apply to EDTA, 1-way antenna. By checking where the arrow is pointing, the user can verify the current control path.

5.6.3. Changing Antenna Configuration

Using Function Key (SEL/MENU, FWD, REV, ENT Key) input the new configuration. Pressing 'SEL/MENU' Key during the process will delete all the inputted figures and send the user back to the previous stage.

1.	Select control path using 'SEL/MENU' key.	
	Diagram: Horizontal Beam Control	01/01 00:00 C HB-X-IB-17-65-00T[a]
		VB1: 0.0° [OK] HB1: 0.0° [OK] VB2:° []
2.	Input desired configuration angle using 'FWD', 'REV' key. Pressing 'FWD' will increase the angle and pressing 'REV' will decrease the angle. If either key is pressed for more than a second, the angle will automatically increase('FWD')/decrease('REV').	



Diagram: Forward Control ($0.0^{\circ} \rightarrow 5.0^{\circ}$)	01/01 00:00 HB-X-IB-17-65-00T[a] VB1: 0.0° [OK] ► HB1: 0.0° [5.0°] VB2:° []
3. Activate antenna beam control by pressing 'ENT'.	01/01 00:00 HB-X-IB-17-65-00T[a] VB1: 0.0° [OK] ► HB1: 5.0° [OK] VB2:° []

5.7. Measurement VSWR

This menu is to measure VSWR, but is not used currently.

5.8. Memory Clear

This menu is to allow users to clear the logging data stored in memory. The current PAC-I can store up to 400Frame logging data. If data is stored more than 395Frame while operating PAC-I, the warning message ('Memory Full') will appear. In such case, the user has to print the logging data, then perform 'Memory Clear' to prevent any damage to the stored data. From SET UP menu screen, press '4' on the keypad to perform 'Memory Clear.'

 Press 'ENT' key to perform 'Memory Clear' or press 'SEL' key to cancel. In order to minimize damage to the data, user must print the data using PAC PC Application program, and then perform 'Memory Clear.' 	01/01 00:00 MEMORY CLEAR YES : <ent> Key NO : <sel> Key</sel></ent>
---	---



6. PAC Menu Structure

6.4. Menu Diagram

Figure 6-1. PAC Menu Diagram Structure Overview





7. PAC PC Application User's Guide

7.4. Operating Environment

- Operating System: Windows 95/98/ME/2000/XP/NT
- Processor: Pentium 500 MHz or higher
- Memory: 128 MB RAM or higher

7.5. Program Installation and Execution

- 7.5.1.1. Insert companion CD in to the CD/DVD drive of your PC.
- 7.5.1.2. Run 'PAC PC application.exe' and follow the on-screen instructions to install the program to the desired directory.

Choose Destination Lo	ocation
	Setup will install PAC in the following folder.
	To install to this folder, click Next.
	To install to a different folder, click Browse and select another folder.
	You can choose not to install PAC by clicking Cancel to exit Setup.
12	Destination Folder
ling	C:\Program Files\KMW\PAC
	< <u>B</u> ack <u>N</u> ext > Cancel

Figure 4-1. Program Installation Destination Selection Window

7.5.1.3. After the program has been successfully installed, run the PAC Application program by selecting 'START' → 'All Programs' → 'Portable Antenna Controller' → 'PAC' from the Windows menu.

7.6. Start-up Window

When you run the PAC program, the following window will appear.

Note: This program cannot be run simultaneously for more than one window on a single PC.



Important: This program requires at least one available serial port (i.e., COM1, COM2, COM3, or COM4). If the serial port is not installed or available, the following error message will appear.



Pac	
⚠	The Selected COM Port is used another application or not installed port .
	OK

Figure 4-3. PAC Program Start-up Window

📃 Portable Antenna Controller 📃 🗔 🗙
<u>F</u> ile <u>P</u> ort <u>V</u> iew <u>H</u> elp
📃 🚈 🗶 📓 🤮 📽 🧣
TX/RX State
Control Button
USER INFO
Ready NUM NUM

• TX/RX State

The TX LED flashes when data is being transferred from the PC to the PAC and the RX LED flashes when data is being received from the PAC to the PC.

Note: If the TX LED is not flashing when sending data to PAC, make sure that a serial port has been opened from the **Port** menu. If RX LED is not flashing after sending data to the PAC for a long time (i.e., exceeding the Timeout period), check the status of PAC if it's powered-on or the serial cable in between.

• USER INFO

Used to set up User ID and Password.

• BTS INFO

Used to set up Base Station (BTS) ID.

• DATA LOG

Used to read the LOG DATA from the PAC.



• DOWNLOAD

Used to download new version of the PAC program to the PAC's ROM.

7.7. Getting Started

7.7.1. Port Setup

Select **Port** menu from the window (Figure 4-4) and select **Port** Set menu from the pull-down menu to launch PORT Properties setup window (Figure 4-5).



Figure 4-4. Port Setup Menu

Figure 4-5. PORT Properties Window

PORT Properties 🛛 🔀									
PORT COM1	▼ BAUD	19200 bps 🔻	Update(<u>U)</u>						
O 4 Bits	PARITY BIT	STOP BIT	0K(<u>0</u>)						
O 5 Bits O 6 Bits	O Odd O Even	O 1.5 Bit	Cancel(<u>C)</u>						
⊙ 8 Bits	O Space	O 2 Bit	(< <detail(<u>D)</detail(<u>						

Select the serial port number (COM1, for example) that is connected to the PAC, set BAUD rate to 19200 bps, DATA BIT to 8 Bits, PARITY BIT to None, STOP BIT to 1 Bit, and click 'OK (\underline{O})' button.

Note: Once the port properties have been set up, the configuration is stored on to the PC so that the selected port is automatically connected and opened the next time the program is ran.

7.7.2. User Information

Select <u>View</u> \rightarrow User Information from the menu or click USER INFO button to set up the authorized user information.



Important: Before registering new users, make sure to down load the existing user information from the PAC by clicking **Get User** button FIRST.

USE	USER Information						
USE	R Information	on M Paul Peter	Jser List M Shannon	Mark	ADD EDIT DELETE		
					Set User Get User		
					Close		

Figure 4-6. User Information Window

• ADD

Used to register new user ID (up to 8 characters) and password (four digit number). The maximum number of users is 10.

User Add & Edit Window	$\mathbf{\Sigma}$
User Name : KMW	
Password : ****	
Confirm Password : ****	
Input Close	



• EDIT

Used to change user ID (up to 8 characters) or password (four digit number). Select the user ID to be edited, change user ID or password, and click **Input** button.

• DELETE

Used to delete user ID from the User List. Select the user ID to be deleted and then click the **DELETE** button to delete.

• SET USER

Used to send the new user list information to the PAC. After updating the user list, click this **SET USER** button to download the new user list information to the PAC's ROM.

• GET USER

Used to retrieve the user list information stored on the PAC's ROM to the PC.

7.7.3. BTS Information

Select <u>View</u> \rightarrow BTS Information from the menu or click BTS INFO button to set up the base station information.

Important: Before registering new cell site base stations, make sure to down load the existing BTS information from the PAC by clicking **Get BTS** button FIRST.

BTS Information						
BTS Information BTS List Site 091 Site 157 Site 232 Site 831	ADD EDIT DELETE					
	Set BTS					
	Get BTS					
	Close					

Figure 4-8. BTS Information Window

• ADD

Used to register new BTS ID (up to 10 characters). The maximum number of BTS ID's is 10.



Figure 4-9. BTS Add & Edit Window

BTS Add & Edit Window 🛛 🔀					
BTS Name : Site 117					
Input Close					

• EDIT

Used to change BTS ID (up to 10 characters). Select the BTS ID to be edited, change BTS ID, and click **Input** button.

• DELETE

Used to delete BTS ID from the BTS List. Select the BTS ID to be deleted and then click the **DELETE** button to delete.

• SET BTS

Used to send the new BTS list information to the PAC. After updating the BTS list, click this **SET BTS** button to download the new BTS list information to the PAC's ROM.

• GET BTS

Used to retrieve the BTS list information stored on the PAC's ROM to the PC.

7.7.4. Data Log

Select <u>View</u> \rightarrow Control Data Log from the menu or click DATA LOG button to view all the control history log of the PAC. To download the data log from the PAC, click Data Out button. Once data log has been retrieved from the PAC, clicking the Print button can print out the information displayed.

Important: Once data log has been retrieved from the PAC, all data log information stored on the PAC is erased. Therefore, if you want to keep the data log information, print out the data log to make a hard copy and store it in a safe place.

ata Log	, Window										
	-	[]				-					1
NO.	Date	Time	BTS Name	User	ANT. Model	Sector	VER.	HOR.	VER. Alarm	HOR. Alarm	⊥≏
0	01/02/03	04/05/06	KMW_BTS_**	KMW_KMW8	CEL800M V20 H60	Gamma	1.5	-26.0	Same Code	Max Code	
1	02/03/04	05/06/07	KMW_BTS_**	KMW_KMW8	CEL800M V14 H30	Alpha	0.0	-21.0	Same Code	Same Code	
2	03/04/05	06/07/08	KMW_BTS_**	KMW_KMW8	CEL800M V20	Alpha	1.5		Unknown Code		
3	04/05/06	07/08/09	KMW_BTS_**	KMW_KMW8	GSM1800M V16 H30	Alpha	4.0	-27.0	Next Code	Same Code	
4	05/06/07	08/09/10	KMW_BTS_**	KMW_KMW8	US PCS V16	Beta	0.5		Next Code		
5	06/07/08	09/10/11	KMW_BTS_**	KMW_KMW8	CEL800M V14 H60	Alpha	1.5	-25.0	Min Code	Good	
6	07/08/09	10/11/12	KMW_BTS_**	KMW_KMW8	GSM1800M V16	Beta	2.5		Mis Code		
7	08/09/10	11/12/13	KMW_BTS_**	KMW_KMW8	GSM900M V13 H30	Alpha	3.0	-22.0	Min Code	Mis Code	_
8	09/10/11	12/13/14	KMW_BTS_**	KMW_KMW8	IMT2000 V16 H30	Beta	1.0	-26.0	Next Code	Min Code	
9	10/11/12	13/14/15	KMW_BTS_**	KMW_KMW8	IMT2000 V16	Beta	0.0		Same Code		
10	11/12/13	14/15/16	KMW BTS **	KMW KMW8	US PCS V16 H30	Gamma	6.0	-23.0	Good	Open Code	
11	12/13/14	15/16/17	KMW_BTS_**	KMW_KMW8	CEL800M V14	Gamma	5.5		Next Code		
12	13/14/15	16/17/18	KMW BTS **	KMW_KMW8	GSM900M V13	Alpha	4.0		Next Code		
13	14/15/16	17/18/19	KMW BTS **	KMW_KMW8	CEL800M V20 H60	Gamma	6.0	-32.0	Max Code	Open Code	
14	15/16/17	18/19/20	KMW BTS **	KMW_KMW8	US PCS V16	Gamma	0.0		Unknown Code		
15	16/17/18	19/20/21	KMW BTS **	KMW_KMW8	CEL800M V14	Alpha	2.0		Same Code		
16	17/18/19	20/21/22	KMW BTS **	KMW_KMW8	CEL800M V14 H30	Alpha	5.0	-27.0	Same Code	Unknown Code	
17	18/19/20	21/22/23	KMW BTS **	KWW_KWW8	IMT2000 V16 H15	Alpha	3.0	-21.0	Same Code	Open Code	
18	19/20/21	22/23/24	KMW BTS **	KWW_KWW8	CEL800M V20 H60	Alpha	1.5	-30.0	Max Code	Good	
19	20/21/22	23/24/25	KMW BTS **	KWW_KWW8	US PCS V16 H15	Alpha	5.0	-20.0	Same Code	Good	
20	21/22/23	24/25/26	KMW BTS **	KMW_KMW8	GSM900M V13	Alpha	4.5		Unknown Code		
21	22/23/24	25/26/27	KMW BTS **	KWW_KWW8	CEL800M V14 H60	Beta	0.5	-31.0	Next Code	Next Code	
22	23/24/25	26/27/28	KMW BTS **	KWW_KWW8	IMT2000 V16 H30	Beta	2.0	-21.0	Unknown Code	Mis Code	
23	24/25/26	27/28/29	KMW BTS **	KWW KMW8	CEL800M V14 H60	Alpha	0.0	-30.0	Same Code	Mis Code	
24	25/26/27	28/29/30	KMW BTS **	KWW_KWW8	CEL800M V20	Gamma	4.0		Min Code		
25	26/27/28	29/30/31	KMW BTS **	KMW_KMW8	CEL800M V14 H30	Beta	5.5	-28.0	Min Code	Good	
26	27/28/29	30/31/32	KMW BTS **	KMW_KMW8	US PCS V16	Gamma	1.5		Open Code		
27	28/29/30	31/32/33	KMW BTS **	KWW KMW8	CEL800M V20 H30	Gamma	35	-23.0	Unknown Code	Same Code	
28	29/30/31	32/33/34	KMW BTS **	KMW_KMW8	GSM900M V13	Gamma	4 0		Next Code		-
					Test		[Data C	Out Print	Close	

7.7.5. Download

Select <u>View</u> \rightarrow **Download** from the menu or click **Download** button to download an updated version of the PAC software on to the PAC's ROM. Click button and select the *.**HEX** file supplied by KMW Communications, then click **Download** button to download on to the PAC.

Important: Do not send any other command while downloading is in progress. Once download is complete, reset the power by turning off and turning on the PAC.

PAC[Portable Antenna Controller] - Downloder						
Download File :	C:₩pac_i_V102.hex					
		Download Cancel				

7.7.6. TX/RX Data Log

Select <u>View \rightarrow TX/RX Data Log</u> from the menu to see transmit and receive data log.



Figure 4-12. TX/RX Data Log Menu





🚓 TX/RX Data Log 🛛 🛛 🔀
You have a good look TX and RX data. If you click the clear button , All data Clear Clear Cancel
SND => 16 16 16 16 02 01 00 00 01 03
RCV => 16 16 16 16 02 01 79 00 00 31 31 31 31 31 31 31 31 31 31 31 31 31
CMD_GETUSERINFO - RET_OK USER NO[0A]
SND => 16 16 16 16 02 02 78 00 30 30 30 30 30 30 30 30 30 30 30 30
RCV => 16 16 16 02 02 01 00 00 03 03
CMD_SETUSERINFO - RET_OK USER NO[0A]
SND => 16 16 16 02 03 00 00 03 03
RCV => 16 16 16 16 02 03 15 00 00 4A 6F 61 6B 64 6F 00 00 00 00 53 49 50 41 4C 00 00 00 00 75 03
CMD_GETBTSINFO - RET_OK BTS NO[02]
SND => 16 16 16 16 02 04 14 00 4A 6F 61 6B 64 6F 00 00 00 00 53 49 50 41 4C 00 00 00 00 73 03
RCV => 16 16 16 02 04 01 00 00 05 03
CMD_SETBTSINFO - RET_OK BTS NO[02]

The Figure 4-13 (TX/RX Data Log Window) shows the actual data communication between the PC and the PAC and this window is used for debugging purpose. To clear the TX/RX Data Log, click **Clear** button.

Displayed Character	Description	Note
SND	Data transfer from PC to PAC.	
RCV	Data transfer from PAC to PC.	



8. Cautions

- This Portable Antenna Controller (PAC) is designed to withstand nominal shock or impact. However, do not drop, throw, or hit while carrying or operating.
- This PAC uses a built-in rechargeable battery with over-charge and over-drain protection circuits. However, excessive over-charge or discharge may degrade the performance and the life of the battery.
- To recharge the built-in battery or use AC power, use the AC/DC adaptor supplied by KMW ONLY.
- Use KMW provided accessories or batteries ONLY with the PAC.
- Unauthorized modification, dismantle, repair of any KMW components voids KMW's warranty.
- This PAC cannot be used with any 3rd party antenna products.
- For any technical support or repair, contact KMW Technical Support at +1-562-926-2033 or at support@kmwcomm.com.



10. Portable Antenna Controller Specifications

Item	Specification
Communication Interface	RS-232 (DSUB 9Pin, Female), RS-485/422 (DSUB 9Pin, Male)
Communication Speed	19200 bps (Max 115200 bps)
Antenna Control Interface	KMW Proprietary Interface (SMA, Female)
LCD	128 ? 64 Graphic LCD
KEY PAD	4 ? 4 Key Matrix type, Membrane Switch
Rechargeable Battery	11.1V (3.7V 3CELL), 1.5AH, LI-POLYMER
External Power	19V, 3.68A, AC/DC SMPS Adaptor
Weight	Approx. 750g (including Rechargeable Battery)
Size	129 ? 214 ? 47 mm
Compatibility/Controllability	All KMW Remote Antenna Products (EDTA 1-way, Hybrid 2-way)
Antenna Control Time	Less than 2 min. (MAX) for each control dimension (Vertical or
	Horizontal)

Note: The above specifications are subject to change without notice. KMW reserves the rights to, without notice, make changes in equipment design or components as engineering and manufacturing requirements demand.

11. Technical Support

For more information on KMW's products and other useful information, visit our website at http://www.kmwcomm.com.

If you have any technical questions or need support, please contact:

KMW Communications Technical Support 1521East Ornagethorpe Ave. Suite A. Fullerton,CA 92831 1-714-895-3659 (Phone) 1-714-898-5025 (Fax) http://www.kmwcomm.com support@kmwcomm.com



Reader Survey Form

Please use this form to rate the usefulness of this user's guide. After filling out the survey, mail or FAX the form to KMW Communications at the address or FAX number shown below.

	Very Useful			Needs Improvement			
Chapter 1. Preface	5	4	3	2	1	0	
Chapter 2. Overview of PAC Kit	5	4	3	2	1	0	
Chapter 3. Overview of PAC-I	5	4	3	2	1	0	
Chapter 4. Operating PAC-I	5	4	3	2	1	0	
Chapter 5. Operating PAC-I		4	3	2	1	0	
Chapter 6. PAC Menu Structure	5	4	3	2	1	0	
Chapter 7. PC Application User's Guide	5	4	3	2	1	0	
Chapter 8. Cautions	5	4	3	2	1	0	
Chapter 9. Troubleshooting Guide	5	4	3	2	1	0	
Chapter 10. PAC Specifications	5	4	3	2	1	0	
What improvement would you like to see?							
Add more detail to the instructions.	Add more examples.						
Add more detail to the diagrams.	Other						
Details:							
Additional Comments or Suggestions:							
Reader Name		Plazca ca	nd this	form to:			
	-	i icuse se	na uns	101111 to.			
Address:		_ KMW Communications					
		1521 East	Orange	ethorpe A	Ave.		
		Suite A. Fullerton	, CA 92	831			
Email:		FAX: +1-714-895-5025					